

AD2020EA Force Value Display Controller

Instruction Manual

Before using this product, please read this instruction manual carefully. Use it correctly and store it properly after fully understanding its contents, so that you can...

Refer as needed.

⚠ If the failure or abnormality of this product could potentially lead to a serious system accident, please install appropriate protective circuits externally.

⚠ Do not use in locations with flammable or explosive gases, corrosive gases, dust, salt, or high concentrations of metal powder.

⚠ Please avoid installing in locations with drastic temperature fluctuations (which may cause condensation) or in areas where heat accumulation might occur due to thermal radiation, etc.

⚠ The instructions are subject to change without prior notice. Please refer to the latest version when consulting them. If you have any questions, please contact our company.

⚠ Our company shall not be liable for any direct or indirect losses other than those caused by the product itself.


1. Technical Specifications

Supply voltage	DC:12V-30V
Input sensitivity	0.4mV/V~6mV/V
Display window	Double-row six-digit LED
Sensor excitation voltage	±2%, 100mA (up to 4 sensors, each with 350Ω)
A/D Performance	24 Bit, Delta-Sigma Method
Display accuracy	1/300000
Output rate	10 40/80/120/200/400/600/800/1200/1600/2400/4800 times per second
Baud rate	1200/2400/4800/9600/19200/38400/57600/115200/230400/460800/921600
Operating temperature	0~60°C
Withstand voltage	1 minute at 2000V AC 50/60Hz
Agreement	Modbus RTU, ASCII, and Free (Free Protocol)
Digital input/output	5 Point transistor output (maximum 1A), 2-point relay output, 4-point input
Serial port	RS485+RS232
Analog (optional)	0~20mA, 4~20mA, 0~±5V, 0~±10V; resolution 1/60000

2. Install

Warning ⚠!

External dimensions (The following drawings are for reference only; the actual product shall prevail.)




3. Wiring

Warning ⚠!

To prevent electric shock and machine malfunction, be sure to energize the equipment only after confirming that the wiring is correct, and verify the energization range.

⚠ Terminal configuration (if TEDS functionality is added, the wiring terminals should be changed to DB9 plug)



0.1 Power Wiring

Symbol	DC+	DC-
Wiring	Positive power,	negative power

0.2 Sensor Wiring (This instrument requires a resistance strain-gage bridge sensor, and the wiring method is four-wire connection.)


Compliant	EXC+	EXC-	SHD	SIG+	SIG-
Wiring	Excitation Voltage+	Excitation Voltage-	Shielding	Signal+	Signal-

Note: When using a six-wire sensor, you should short-circuit the sensor's EXC+ and SIG+ terminals and then connect them to the instrument's EXC+ port. EXC-Short-circuit to the SIG-port on the meter.

- Since the sensor output signal is an analog signal that is highly sensitive to electronic noise, the sensor wiring should use... Shield the cable and lay it separately from other cables, especially keeping it away from AC power sources.
- For applications involving parallel connection of multiple sensors, it is essential to ensure that the sensitivity (mV/V) of each sensor is consistent.

0.3 Serial Port Wiring

Symbol	A	B	Txd	Rxd	Gnd
Wiring	A	B	Rxd	Txd	Gnd



0.4 Analog Wiring

Symbol	VO	IO	AN-
Current output wiring			AN-
Voltage output wiring			AN-

0.5 Digital Input Wiring

This instrument uses optoelectronic isolation for its digital input/output signals, and the interface requires an external 24V DC power supply to provide the operating voltage for the digital signals.

The power supply's positive terminal is connected to the instrument's PV+, and its negative terminal is connected to PV-. It features both relay and transistor outputs, with the crystal...

The output is configured as an open-collector output.

Transistor output ports: PD+, PD-, OUT1~OUT5


Relay output ports: COM, OUT6, OUT7

Input ports: COM, IN1~IN4

Protection of DC relays

Apply a resistor-capacitor network in a low-voltage (DC 30V) DC relay circuit, connecting it across the load to form a relay...

The DC relay protection circuit for DC loads driven by electrical appliances is shown in the figure below:




Note: In the above figure, the external power supply VCC range is 10-30 VDC.


Protection of AC Relays

When using an AC relay to control a load, it is recommended to connect a resistor-capacitor network in parallel with the AC relay, along with a variable resistor, for protection.


Protect, as shown in the figure below:



Digital Output Wiring Diagram




Digital Input Wiring Diagram




4. Basic operations

Panel and Button Instructions



Name	Instructions
Display window (1)	Main interface: Displays gross weight. Menu operation interface: Menu
Display window (2)	Main interface: Displays peak value, valley value, and peak-to-valley value. Menu operation interface: Menu content and values
Weight indicator	g: gram; kg: kilogram; t: ton; N: newton; All weight indicators off: Custom unit
Peak	Main interface: Press keys to switch display values: Gross weight: The display window (1) always shows the gross weight. Peak: The window (2) Peak light is on. Valley: The window (2) Valley light is on.
Valley	Peak-Valley Value: The Peak and Valley lights in window (2) are on.
Mot	Light on: Current value is unstable; light off: Current value is stable.
Zero	Light on: The current weight value is 0.
IN1	Light on: Input port 1 is enabled
IN3	Light on: Input port 3 is enabled
OUT1	Light on: Output port 1 is enabled.
OUT3	Light on: Output port 3 is enabled.
OUT5	Light on: Output port 5 is enabled.
OUT7	Light on: Output port 7 is enabled.

Button	Function Description
SWITCH	Main interface: Switch window (2) displays values (peak, trough, peak-to-trough). Menu interface: Scroll up the menu. Editing interface: When modifying a value, move the modification position to the left.
CALI	Main interface: Enter the calibration menu. Menu interface: Scroll down the menu. Editing interface: When modifying a value, move the modification position to the right.
ZERO	Main interface: Clear gross weight, clear peak and valley values. Menu interface: Scroll up the menu. Edit interface: Scroll up when in selection state / increase value when modifying a numerical value.
OFTEN	Main interface: Enter the frequently used menu. Menu interface: Scroll down the menu. Edit interface: When in selection mode, scroll down to decrease the value/modify the numerical value.
ENT SET	Main interface: Short press to enter the settings menu; press and hold for more than 2 seconds without releasing to enter the calibration menu. Menu interface: Enter the sub-level interface. Edit interface: Save and return to the previous level.
ESC	Menu interface: Return to the parent level. Edit interface: Don't save and return to the previous level.



6. Parameter Overview

Name	Symbol	Content
F1	F1	Basic Parameters
F2	F2	Peak/Valley Parameter
F3	F3	Comparator parameters
F6	F6	Digital parameter
F7	F7	Communication parameters
F8	F8	Analog parameters
F9	F9	Other parameters

6.1 Basic Parameters

Submenu	Parameter Name	Value range	Default	Analysis
F1-01	Unit Selection	Hg: kilogram; g: gram; n: newton; t: ton; nonE: Custom	Hg	8.1.1
F1-02	Power-on reset range	External weight unit	000000	8.1.2
F1-03	Manual zeroing range	External weight unit	000500	8.1.3
F1-04	Stability range	0~9999, consistent with the real-time	000000	8.1.4
F1-05	Stabilization time	0.1~5.0 seconds, in increments of 0.1	0.5	8.1.4
F1-06	Zero-point range	0~99, consistent with the real-time	000000	8.1.5
F1-07	Automatic zero-position	0~15.0, consistent with the real-time	000000	8.1.6
F1-08	Automatic zero-position	0~5.0, unit: 0.1 second	0.5	8.1.6
F1-09	Creep tracking range	0~9.999, unit: 0.001 division	0.050	8.1.7
F1-10	Creep tracking time	0~999.9, unit: 0.1 second	002.0	8.1.7
F1-11	AD conversion speed	1040, 80, 120, 200, 400600, 800, 1200, 16002400, 4800 times/second	10	8.1.8
F1-12	Filter Type	0 Do not use Compound filtering (recommended) 2 Median filter 3: First-order filtering 4 Moving average filtering 5 Median Average Filtering 6 Median Moving Average Filtering 7 Average filtering + First-order filtering 8 Median filtering + First-order filtering 9 Sliding average filtering + first-order filtering 10 Median average filtering + first-order filtering		8.1.9
F1-13	First-level filtering intensity	0~50	06	8.1.9
F1-14	Number of first-level filtering iterations	0~9	0	8.1.10
F1-15	Secondary filter intensity	0~9	0	8.1.10
F1-16	Stable filtering	on: on; off: off	off	8.1.10
F1-17	AD resolution	16~24 bits	24	8.1.11
F1-18	Whether negative numbers are displayed	-1234 Display positive and negative numbers; 1234 Show only positive numbers	-1234	8.1.12

6.2 Peak/Valley Parameters

Submenu	Parameter Name	Value range	Default value	Analysis
F2-01	Peak detection method	nonE: Disable peak detection Hr: Start peak detection after the force value exceeds the peak threshold. EER: Start peak detection when an external signal is present (ignore threshold Value), end peak detection when there is no external signal.	nonE	8.2

F2-02	Peak threshold	0~99999~999999, consistent with the real-time weight	000000	unit	8.2
F2-03	Peak hysteresis	0~999,999, consistent with the real-time weight	000000	unit	8.2
F2-04	Valley detection Can method	nonE: Disable valley detection HrL: Start valley detection after the force value falls below the valley threshold. The valley threshold is set on external activation and when the valley threshold is met. Er: Start valley detection when an external signal is present (ignore threshold Value), end valley detection when there is no external signal.	000000	unit	8.2
F2-05	Minimum threshold	0~99999~999999, consistent with the real-time weight	000000	unit	8.2
F2-06	Valley hysteresis	0~999,999, consistent with the real-time weight	000000	unit	8.2
F2-07	Peak/Valley Detection Measure interval time	0~2.55 seconds	0.50		8.2

F3 Comparator Parameters		
Symbol	Instructions	Analysis
F3-1	Comparator 1 parameter	8.3
F3-2	Comparator 2 parameter	8.3
F3-3	Comparator 3 parameter	8.3
F3-4	Comparator, 4 parameter	8.3
F3-5	Comparator 5 parameter	8.3
F3-6	Comparator 6 parameter	8.3

Comparator N parameter (N refers to 1 or 2)				
Symbol	Parameter Name	Value range	Default value	Analysis
F3-1.1 F3-2.1 F3-3.1 F3-4.1 F3-5.1 F3-6.1	Compare enable mode	nonE: Comparator off By the comparator starts immediately upon power-on. Er: External Signal Start/Stop Comparator	000000	
F3-1.2 F3-2.2 F3-3.2 F3-4.2 F3-5.2 F3-6.2	Comparison judgment condition	0Force value ≥ upper limit 1:Mid-range ≤ Force ≤ Upper limit 2Lower limit < Force value ≤ Middle limit 3Force value ≤ lower limit 4Force value ≥ upper limit, lower limit < force value ≤ middle limit 5Force value ≥ upper limit, Force value ≤ lower limit 6Force value ≤ lower limit, middle limit < force value ≤ upper limit	0	8.3.1
F3-1.3 F3-2.3 F3-3.3 F3-4.3 F3-5.3 F3-6.3	Compare data source	Gross: Gross weight Measured value PEAK: Peak-to-valley value VALLEY: Valley minimum PEAK: Peak nEt: Net weight	000000	
F3-1.4 F3-2.4 F3-3.4 F3-4.4 F3-5.4 F3-6.4	Compare latency	0~25.5 seconds	00.1	8.3.2
F3-1.5 F3-2.5 F3-3.5 F3-4.5 F3-5.5 F3-6.5	Compare the upper limit	~99999~999999, with real-time weight unit one	099999	
F3-1.6 F3-2.6 F3-3.6 F3-4.6 F3-5.6 F3-6.6	Comparison of median limits	~99999~999999, with real-time weight unit one	000000	
F3-1.7 F3-2.7 F3-3.7 F3-4.7 F3-5.7 F3-6.7	Compare the lower limit value	~99999~999999, with real-time weight unit one	099999	
F3-1.8 F3-2.8 F3-3.8 F3-4.8 F3-5.8 F3-6.8	Comparison judgment condition on: Only perform the judgment when the weight is stable	off: Compare judgments under any circumstances	000000	
F3-1.9 F3-2.9 F3-3.9 F3-4.9 F3-5.9 F3-6.9	Comparator threshold	~99999~999999, with real-time weight unit one	000000	

F6 Digital Input Parameters				
Submenu	Parameter Name	Value range	Default value	Analysis
F6-00	Output port test	OUT1:o1.on/o1.oFF OUT2:o2.on/o2.oFF OUT3:o3.on/o3.oFF OUT4:o4.on/o4.oFF OUT5:o5.on/o5.oFF OUT6:o6.on/o6.oFF OUT7:o7.on/o7.oFF	0.1oFF	8.4.1
F6-01	Output Port 1 Setting	0Communication Control 1: Zero Point	10	8.4.2
F6-02	Output Port 2 Setting	2Stable 3Overload 4: Alarm	12	
F6-03	Output Port 3 Setting	10Comparator 1 Result	12	
F6-04	Output Port 4 Setting	11Comparator 2 result	13	
F6-05	Output Port 5 Settings	12Comparator 3 results	14	
F6-06	Output Port 6 Settings	13Comparator 4 results	15	
F6-07	Output Port 7 Settings	14Comparator 5 results	15	
F6-50	Enter valid time	0.01~2.55 seconds	0.05	8.4.3
F6-51	Input Port 1 Settings	0Do not use zero-CAL 1: Zero Point	0	8.4.4
F6-52		3Clear skinStart peak/valley detection	0	
F6-53		5: Clear peak/valley values	0	
F6-54		10Start comparator 1 11Enable Comparator 2 12Start comparator 3 13Start comparator 4 14Start comparator 5 15Start comparator 6	0	

F7 Communication Parameters		
Symbol	Instructions	Submenu
F7.485	For RS485 interface	F7.101~F7.114
F7.232	For RS232 interface	F7.201~F7.214

F7 Communication Parameters				
Submenu	Parameter Name	Value range	Default value	Analysis
F7.101	RTU: Modbus RTU protocol	FREE: Free protocol	000000	
F7.201	Protocol Type	ASC: ASCII protocol	000000	
F7.102	Baud Rate	1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800	9600	
F7.202	Baud Rate	1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800	9600	
F7.103	Mailing address	1~247	001	
F7.203	Mailing address	1~247	001	
F7.104	Data frame format	8-n-2: 8 data bits; no parity; 2 stop bits 8-n-1: 8 data bits; no parity; 1 stop bit 8-o-1: 8 data bits; odd parity; 1 stop bit 8-E-1: 8 data bits; even parity; 1 stop bit 7-n-2: 7 data bits; no parity; 2 stop bits 7-o-1: 7 data bits; odd parity; 1 stop bit 7-E-1: 7 data bits; even parity; 1 stop bit	000000	
F7.105	Response Delay	0~255 milliseconds	000	
F7.106	Verification	off: Disable CRC check on: Enable CRC check (Modbus RTU protocol invalid) off	000000	
F7.107	High and low setting	HH-LL: 32-bit data is stored with the high-order bits first, followed by the low-order bits. HH-HH: 32-bit data is first placed in the lower bits, then in the high bits. (Only the Modbus RTU protocol is valid.)	000000	
F7.110	Continuous Transmission	on: Enable continuous sending transmission	000000	9.1.1
F7.111	Send data continuously	Gross: Gross weight value EAS: Measure-valley value VALLEY: Valley minimum PEAK: Peak nEt: Net weight	000000	9.1.1
F7.112	Data Update Method	on: Send only when data is updated.	000000	9.1.1
F7.113	Interval Time	0~60,000 seconds	00.000	9.1.1
F7.114	format	Std: Standard format SÉP: Simple Format SÉP2: Simple Format 2	Std	9.1.1

F8 Analog Parameter				
F8 Analog Parameters				
Submenu	Parameter Name	Value range	Default value	Analysis
F8-01	Analog Output Type	n-5v:0~±5V n-10u:0~±10V 4-20E:4~20mA 0-20E:0~20mA	n-10u	8.5

F8-02	Analog Output Data Source	Gross: Gross weight EAS: Measured value PEAK: Peak Valley value VALLEY: Valley minimum PEAK: Peak nEt: Net weight	000000	
F8-03	First analog quantity	-9.999~25.000	00.000	8.5
F8-04	The second analog quantity	-9.999~25.000	10.000	8.5
F8-05	First point weight	~99999~999999, with real-time replay	000000	8.5
F8-06	Second point weight	~99999~999999, with real-time replay	010000	8.5
F8-07	Fine-tune the first analog signal	S1 Adj:0.001 V(mA); n1 Adj:0.01 V(mA);	n1 Adj	8.5
F8-08	Fine-tune the second analog signal	S1 Adj:0.001 V(mA); n1 Adj:0.01 V(mA);	n1 Adj	8.5
F8-09	Third analog signal	-9.999~25.000	00.000	8.5
F8-10	Third point weight	~999999~999999, with real-time replay	000000	8.5
F8-11	Fine-tune the third analog signal	S1 Adj:0.001 V(mA); n1 Adj:0.01 V(mA);	n1 Adj	8.5

F9 Other parameters				
Submenu	Parameter Name	Value range	Default value	Analysis
F9-01	Display refresh rate	001~200 times/second	010	8.6.1
F9-02	TEDS scan	off: Detect TEDS sensors only when power is applied. on: Scan the TEDS sensor every 1 second. (Only supported by the TEDS version)	000000	
F9-03	Sensor millivolt value	-39.000mV~39.000mV	Real-time value	
F9-04	Parameter menu password	000000~999999		
F9-05	Restore default parameter	Restore all parameters from F1 to F9		8.6.4
F9-06	Version number	Firmware version number		8.6.5
F9-09	Fault Prompt Type	off: No prompt one: Prompt only once YonEr: Interval Prompt	off	8.6.6
F9-10	Fault notification interval	00001~34,463, unit: seconds	00010	8.6.7

7 Calibration and verification

When a user first uses this instrument, or when any part of the measurement system has changed, as well as when the calibration parameters of the current device are updated.

When the instrument fails to meet the user's requirements, it should be calibrated. Calibration can be performed using weight calibration or digital calibration (no need).

Weight calibration: The calibration can be performed by modifying any one or more of the calibration parameters.


Press the key briefly or long-press the ENT key for more than 2 seconds to enter the calibration wizard. Follow the instructions in the calibration wizard to complete the calibration steps.

The instrument must be powered on for at least 15 minutes before calibration to allow the sensor and the instrument to stabilize.

Before calibrating the new equipment, the weighing body must first be pressed with a weight at full scale for at least 8 hours to stabilize its mechanical structure.

The angular difference must be checked before and after the device is calibrated.

F1 Calibration parameters		
Name	Symbol	Content
CAL1	CAL1	Weight calibration
CAL2	CAL2	Digital calibration
CAL4	CAL4	Calibration password
CAL3	CAL3	Multi-point correction
CAL5	CAL5	Restore calibration parameters
CAL7	CAL7	Display correction parameters



7.2 Calibration Procedure				
Name	Submenu	Parameter Name	Value range	Default value
div	Dev	Degree setting	0.00010.0002, 0.0005, 0.001, 0.0020.005, 0.01, 0.02, 0.05, 0.1, 0.20.5, 1, 2, 5, 10, 20, 50	0.01
CAP	CAP	Maximum weighing capacity	~99999~999999, consistent with the real-time weight unit one	00.00
ZErO	ZErO	Calibrate the zero point	~99999~999999, with real-time weight unit one	00.00
SPAn	SPAn	Calibration range	~99999~999999, with real-time weight unit one	00.00


To

dev(div)---Scale setting, i.e., the smallest graduation--the minimum value that the instrument can read. (For example, a weight of 1000g, when being when divided into 10 equal parts, the graduation value is 100 g; when divided into 100 equal parts, the graduation value is 10 g; and when divided into 1,000 equal parts... The decimal point displayed on the digital tube is related to the scale division; if you select a scale division of 0.1, the display will show up to... 0.0if you select a graduation of 0.01, the display will show up to 0.00.

CAP(CAP)---Maximum weighing capacity, i.e., the sensor's maximum measurement range.

ZER0(ZerO)---ZeroPointCalibration,thatistheweightofthesensorwhenitempty.

SPAn(SPAn)---Gain calibration, i.e., the weight value input after loading weights onto the sensor (It is recommended to use 25% of the full scale range The above weight).



- Enter weight calibration (**CAL1**): Press 0 briefly or press and hold the ENT key for more than 2 seconds to enter **CAL1**.
- Unit Settings (**unEt**): **CAL1** Short press ENT to enter **unEt**, and you'll immediately jump to the settings interface. Use the ← key to switch. Change the unit, save using ENT, and switch to the indexing setting.
- Scale Setting (**dEv**): **CAL1** Short press ENT to enter **dEv**, then press ENT again to enter the scale adjustment mode. Use the ← keys Switch the graduation value, press ENT to save, and then switch to the maximum weighing capacity.
- Maximum weighing (**CAP**): Briefly press ENT to enter the **CAP** modification mode; press rand u/o shift, and press ← to adjust the numerical value. Press ENT to save and switch to **ZErO**.
- Zero Calibration (**ZErO**): After setting **CAP**, briefly press ENT to enter **ZErO**. Immediately afterward, a weight value will appear--empty. With sensor, a short press of ENT will start a 5-second countdown and switch to **SPAn**.
- Gain Calibration (**SPAn**): Load weights (recommended weight exceeding 25% of the sensor's capacity), and briefly press ENT--this will display a real-time value, then briefly press ENT and enter the weight of the loaded weights. Use sand u/o shift, and use ← to adjust the numerical value. Press ENT to save.

CAL2 Digital Calibration				
Name	Submenu	Parameter Name	Value range	Default value
div	Dev	Degree setting	0.00010.0002, 0.0005, 0.001, 0.0020.005, 0.01, 0.02, 0.05, 0.1, 0.20.5, 1, 2, 5, 10, 20, 50	0.01
CAP	CAP	Maximum weighing capacity	~99999~999999, consistent with the real-time weight unit one	00.00
ZErO	ZErO	Calibrate the zero point	~99999~999999, with real-time weight unit one	00.00
SEn	SEn	Calibration sensitivity	0.000~6.000mV/V	2.000
SPAn	SPAn	Calibration range	~99999~999999, with real-time weight unit one	00.00

dEv(div)---Resolution setting, i.e., the smallest scale division--the minimum value that the instrument can display. (For example, for a weight of 1000g; when divided into 10 equal parts, the resolution is 100g; when divided into 100 equal parts, the resolution is 10g; and when divided into 1000 equal parts, the resolution is 1g.) The decimal point displayed on the digital tube is related to the resolution setting. If you select a resolution of 0.1, the display will show up to 0.0; if you select a resolution of 0.01, the display will show up to 0.00.

3.2 Peak/Valley Parameter Description (F2)

On the display screen, you can view peak/valley values by switching the display mode. When you switch to peak display, the Peak indicator light is activated.

Bright—when switching to valley display, the Valley indicator light turns on; when switching to peak-valley display, the Peak and Valley indicators turn on.


The indicator light illuminates simultaneously. When the next peak or trough value appears, the displayed data is overwritten.

Peak threshold: Peak detection is initiated when the measured value exceeds the peak threshold.

Peak Hysteresis: When the measured value drops back to the peak hysteresis setpoint, peak detection stops.

Valley threshold: When the measured value falls below the valley threshold, valley detection is initiated.

Valley hysteresis: When the measured value returns to the valley hysteresis setpoint, valley detection stops.



As shown in the figure above, once the measured value exceeds the "peak threshold," the meter starts detecting the peak. When the measured value begins to drop,

After exceeding the "peak hysteresis," the instrument completes peak detection and obtains the peak value.

After a peak is detected, only when the measured value drops below the "peak threshold" and then rises again above the "peak threshold" ...

Only then can the peak be re-detected. To acquire the peak, the value must exceed the "peak threshold" and the subsequent drop must surpass the "peak hysteresis."

Valley detection is similar to peak detection and will not be described separately.


Maximum value/Minimum value detection:

To obtain the maximum measured value: Set the "Peak Threshold" according to actual needs and set the "Peak Hysteresis" to 0.

To obtain the minimum measured value: Set the "valley threshold" according to actual needs and set the "valley hysteresis" to 0.


3.3 Comparator Parameter Description (F3)

3.3.1 Force value > upper limit




Black 1: force value > upper limit

3.3.2 Middle limit < force value <= upper limit




Black 2: lower limit < force value <= middle limit


3.3.3 force value <= lower limit




Black 3: force value <= lower limit




Black 4: force value > upper limit and lower limit < force value <= middle limit




Black 5: force value >= upper limit force value <= lower limit



Black 6: force value <= lower limit middle limit < force value <= upper limit



Black 7: force value >= upper limit force value <= lower limit



Black 8: force value <= lower limit middle limit < force value <= upper limit

Comparator 1 Setup Steps

3.3.1.1 Turn on the comparator. 3.3.1.2 Select the comparison judgment method. 3.3.1.3 Select the comparison data source.


3.3.1.4 Set comparison delay. According to the comparison judgment method: 3.3.1.5 Set the comparison upper limit. 3.3.1.6 Set

Set the upper limit in the comparator. 3.3.1.7 Set the lower limit in the comparator. 3.3.1.8 Set the comparison condition. 3.3.1.9

Set the comparator threshold (comparison is performed only when the force value exceeds the comparator threshold.)

Comparator 2 The setup steps for this comparator are identical to those for the comparator 1, so we won't describe them separately here.

3.3.2 3-1.4/F3-2.4 Delay Comparison



3.4 Digital Input/Output Parameters (F6-F7)

3.4.1

Enter F6-00, and test whether the port output is normal. When 01.0n is displayed, the CH1 light turns on; when 02.0n is displayed, the CH2 light turns on.

3.4.2 F6-01 Output Port 1 Settings and F6-02 Output Port 2 Settings

Transistor output activation steps:

A: Connect the wires according to the discrete output wiring diagram.

B: Set the output conditions and output ports. OUT1 corresponding to F6-01 Set the conditions, output port OUT2 corresponding to F6-02 Set

Set the condition, output port OUT3 corresponds to F6-03 Set the condition, OUT4 corresponds to F6-04 Set the condition, OUT5 corresponds to

Should F6-05 set the conditions, OUT6 corresponds to F6-06 set the conditions, OUT7 corresponds to F6-07 set the conditions. If you need to...

Compare and output the force values—please select 10~15; comparator 1 results—comparator 6 results, refer to menu F3 and

3.4.3 F6-50 Enter valid time

Set the hold time for the input signal; the larger the setting, the longer the input signal needs to be held, enhancing anti-interference performance.

The better the fruit, the better; the smaller the setting, the faster the response.


The instrument is activated by an external signal fed through the input port, enabling one of the functions selected from F6-51 to F6-54.

The most commonly used function among them is external signal reset.

3.5 Analog Parameter (F8) On the instrument, if you need to output an analog signal, you must enter the F8 menu to configure the analog

Set the quantitative parameters.)

The analog output has a linear relationship with the weight value.



Set the analog output type (F8-01): 0~20mA/4~20mA/0~±10V.

Select the analog data source type (F8-02): Measured value / Gross weight / Net weight / Peak value / Valley value / Peak-to-valley value.

Set the analog values (F8-03) and (F8-04): Set the corresponding first point according to the analog output type selected in F8-01.

Analog input and second analog input (if 0~20mA is selected: the first analog input is 0.000, and the second analog input is

20,000; if you select 4~20mA: The first analog value is 4.000, and the second analog value is 20.000; If you select

Select -10~10V: The first analog value is 0.000, and the second analog value is 10.000.

Set the weight values (F8-05 and F8-06): Enter 0 for the zero-point weight value in F8-05, and enter the full-scale weight value in F8-06.

Fine-tune the first analog point (F8-07) and the second analog point (F8-08): When the first and second analog points...

When the output value deviates, you can make fine adjustments using F8-07 and F8-08 to ensure precise output.

The third analog signal (F8-9) and the third weight (F8-10) can be set selectively. For example, when setting the output to 4~20mA,

Simply set the first analog output to 4mA, and the second analog output to 20mA. If you need to set

At the three points—4mA, 12mA and 20mA—set the analog value for the first point as 4mA, and set the analog value for the second point as

12mA, the third analog setting is 20mA. The three analog settings must be configured in ascending order.

Fine-tune the third analog output (F8-11): When there is a slight deviation in the third analog output, you can use F8-11 for fine adjustment.

After the simulation parameters are set, don't go back to F8-01 to confirm the output type. If you do go back to F8-01, press Confirm again

if you press the key, the voltage or current setting parameters within F8 will revert to their default values. If you want to access F8-01, please exit.

Press the Back key when outputting; the simulated parameters—whether voltage or current—depend on the output. ±10V, ±5V, 0~10V, 0~5V,

4~20mA, 0~20mA Automatically switches; the third-point parameter is not used by default.

3.6 Other parameters (F9)

3.6.1 Display refresh rate

The frequency at which the digital tube display is refreshed.

3.6.2 F9-02 TEDS Scan

For instruments equipped with TEDS, if the TEDS function is unavailable, the F9-02 menu will also be absent.

TEDS function: information such as the sensor's sensitivity and measurement range is imported into the TEDS chip, and the chip is then bonded to.

On the sensor, the instrument can eliminate the need for calibration by recognizing chip data, enabling the on-site measurement system to have automatic calibration functionality.

3.6.3 F9-03 Sensor millivolt signal

Entering the F9-03 menu will display the millivolt value output by the sensor to the instrument; this millivolt value is proportional to the weight reading shown on the instrument.

The sensor's normality can be determined by the millivolt value.

3.6.4 F9-05 Restore default parameters (F9-05 can restore the parameters set using F1~F9 to their factory-default values.)

0a. F9-05 0.8Cont 0.8

(For instruments equipped with a tactile switch, press and hold the zeroing button on the instrument, then power it on. The communication parameters can be reset after 3 seconds.

To the default value)

3.6.5 F9

Products of the same model are distinguished by different version numbers as their functions increase, decrease, or change.

3.6.6 F9-09 Fault Notification Type

In case of an error—for example, when the sensor cable is disconnected—selecting OFF does not trigger an error; selecting ON triggers an error only once; select

Select Enter keeps reporting an error.

3.6.7 F9-10 Fault notification interval

Selected Select Enter When the error keeps occurring, you need to set the interval between two error reports.

3.7 Communication Parameters (F9)

3.7.1 Continuous Transmission Function Setting

By enabling the continuous transmission function, the meter can continuously and uninterruptedly send data to.

3.7.1.1 Free protocol continuous transmission setting

Enter F7.101/F7.201 Select protocol type FrEE.

Go to F7.110/F7.210 and select the "Enable Continuous Transmission" function on.

Enter F7.111/F7.211 Select the continuous data transmission source; generally, choose Gross Weight Gross

Enter F7.112/F7.212 Select the data update method according to customer requirements.

Enter F7.113/F7.213 to select the interval for data transmission.

When setting the interval for continuous transmission, be sure to note that the set time must not be shorter than the time required for one frame. For example:

Okay, if the set baud rate is 9600, then the speed is 9600 bits per second. Since 1 byte = 10 bits, the speed is

is 960 bytes per second, meaning that 1 seconds can transmit 960 bytes. If the continuously sent back format is FE 01 50 00

00 00 06 FC CF CC FF, which means that 12 bytes constitute one frame. Therefore, one frame (12 bytes) requires

The time for is 12/960 = 0.0125 seconds = 12.5 milliseconds. Therefore, when setting the interval for continuous transmission, we must make it sufficiently large.

At 12.5 milliseconds. Of course, you can also increase the baud rate to shorten the interval time.

Enter F7.114/F7.214 Select the format for data transmission.

For example, the resolution is 0.01, and the digital tube displays 0.82. The data returned varies depending on the selected format.

Std: Standard format: FE 01 50 00 00 00 00 52 CF FC CC FF SÉP: Simplified format: 0.82 (if the instrument does not support the ASCII protocol, select the SÉP format; data is transmitted in ASCII

Send in HEX format to the host computer; note that the host computer must be set to display in HEX.) SÉP

P2: Simple Format 2: FE 01 50 00 00 52 CF FC CC FF (data length is only 2 bytes)

3.8 Modbus RTU Protocol

data format: 8 data bits, 1 stop bit, odd parity

8 data bits, 1 stop bits, even parity

8 data bits, 1 stop bits, no parity (default)

One data bit, one stop bit, no parity

aud Rate: 1200, 2400, 4800, 9600 (default), 19200, 38400, 57600, 115200, 230400

460800/921,600 bps

Read register data format (read internal instrument data)

1.Sending format

Module address	Function code	Register start address	Number of registers	CRC16 Check
Addr	03	High 8 bit Low 8 bit	High 8 bit Low 8 bit Low 8 bit High 8 bit	

2.Return format

Module address	Function code	Number of bytes	Register data	CRC16 checksum
Addr	03	N	High 8 bits Low 8 bits	Low 8 bits High 8 bits

0Take gross weight reading as an example

Name	Address	Category	Description	Attribute	Default value
Gross weight (080)	40081 (080)	32 position (Signed integer)	Actual gross weight; negative numbers are represented using the standard two's complement.	Read-only	--

The register addresses are 080 and 081 (if it's a Siemens PLC, please use register addresses 40081 and

40082), then the register starting address is 080 (the hexadecimal representation of 80 is 50), and the number of registers is 2 units. Default

The module address is 01 (when connecting two or more meters in parallel, you must assign different module addresses— 2—so that the host computer can recognize them.

Don't). The function code for reading the register is 03, and the CRC16 checksum is calculated based on all the preceding data 01 03 00 05 00 02.

The calculated result is C4 1A; format the above data according to the read register transmission protocol and compile it into the following instruction: 01 03 00 05 00 02 C4 1A

Module address	Function code	Register start address	Number of registers	CRC16 Check
01	03	00 50	00 02	C4 1A

The register data in the returned data is 00 00 00 84, which represents the gross weight value. The decimal equivalent of 84 is 132.

Module Address	Function Code	Number of Bytes	Register Data—Group 1	Register Data—Group 2	CRC16 Checksum
----------------	---------------	-----------------	-----------------------	-----------------------	----------------

01	03	04	00	00	00	84	FA 50
----	----	----	----	----	----	----	-------

Register data 00 00 00 84 Converted to decimal is 132; if the data is FF FF FE C9, it represents a negative number: FF FF FE

C9-FF FF FF FF = (4294966985 - 4294967295) - 1 = -311. FF FF FF FF represents -1.

Write register data format (overwrite or set internal instrument data)

1.Sending format

Module Address	Function Code	Register Start Address	Number of registers	CRC16 Check
Addr	10	High 8 bit Low 8 bit High 8 bit Low 8 bit	N High 8 bit Low 8 bit Low 8 bit High 8 bit	

2.Return format

Module address	Function code	Register start address	Number of registers	CRC16 Check
Addr	10	High 8 bit Low 8 bit High 8 bit Low 8 bit Low 8 bit High 8 bit		

Take setting the manual zero-range as an example.

Name	Address	Category	Description	Attribute	Default value
Zeroing range	40094 (093)	16 position Unsigned integer	Set the range for zeroing; the unit is a percentage of full scale; Write 0 The manual zero-clearing function is in effect	just write	--

The register address is 093 (if it's a Siemens PLC, please use 40094). For a single register, the register starting address is

is 093 (93 in hexadecimal is 5D), and the number of registers is 1. The default module address is 01 (when connecting 2 units in parallel or using

When connecting to the instrument, you need to set it to 2 different module addresses so that the host computer can recognize them. The function code for writing to registers is 10.

The register data assumption sets the range to 100%, 100, which in hexadecimal is 64. The CRC16 checksum is calculated based on all the preceding

Data 01 10 00 5D 00 01 02 00 64 The converted value is AA F6. Write the above data in register write format

The instruction is 01 10 00 5D 00 01 02 00 64 AA F6.

Module Address	Function Code	Register Start Address	Number of registers	CRC16 Check
01	10	00 5D	00 01	02 00 64 AA F6

Return format 01 10 00 5D 00 01 90 1B

Module address	Function code	Register start address	Number of registers	CRC16 Check
01	10	00 5D	00 01	90 1B

The following are examples of some commonly used commands; for detailed protocol information, please refer to the relevant documentation!

3.2.1 Read Modbus RTU protocol

Send: 01 03 00 50 00 02 C4 1A (Address 80 in hexadecimal is 50)

Reply: 01 03 04 00 00 00 84 FA 50 (Data varies depending on the actual situation) Register data 00 00 00 84, when converted to decimal, is 132. If the data is FF FF FE C9, it represents a negative number. FF FF FE

C9 - FF FF FF FF = (4294966985 - 4294967295) - 1 = -311. FF FF FF FF indicates -1

3.2.2 Weight Calibration (Modbus RTU Protocol)

validate the zero point (clear the weighing platform before sending the zero-point command to ensure the sensor is unloaded)

Send: 01 10 00 24 00 04 08 7F FF FF FF 00 00 00 00 00 8E 7A

Reply: 01 10 00 24 00 04 81 C1

calibrate the gain (add weights, filling at least the full scale 25% or more in weight)

Send: 01 10 00 28 00 04 08 7F FF FF FF 00 00 07 D0 9D C6 (using 2000 as an example) Send: 01 10 00 28 00 04 08 7F FF FF 00 00 0B B8 99 28 (using 3000 as

an example) Send: 01 10 00 28 00 04 08 7F FF FF FF 00 00 13 88 93 3C (using 5000 as an example) Send: 01 10 00 28 00 04 08 7F FF FF 00 00 27 10 EA 56 (using 10000 as

data format: 8 data bits, 1 stop bit, no parity (default)

aud Rate: 1200, 2400, 4800, **9600** (default), 19200, 38400, 57600, 115200, 230400
460800, 921,600 bps

1. Sending format

Frame header	Address	Instruction	Instruction parameter	CRC Check	optional	Frame end
FE	Addr	1 Byte	0~255 byte high 8 bit	Low 8 bits		CF FC CC FF

2. Handshake successful response

Frame header	Address	Instruction	CRC Check (optional)	Frame end
FE	Addr	F1	High 8 bits low 8 bits	CF FC CC FF

• Inger-grip command (default address is 1)

Category Name	Instruction	Instruction Parameters	Instruction Description
System	handshake	0x00	After receiving the command, the module sends 0xF1 to the host to indicate successful handshake. Return format: FE ADDR F1 CF FC CC FF

Transmission format: FE 01 00 CF FC CC FF

Frame header	Address	Instruction	Instruction parameter	Frame end
FE	01	00		CF FC CC FF

Return format: FE 01 F1 CF FC CC FF

Frame header	Address	Instruction	Frame end
FE	01	F1	CF FC CC FF

3. Write instruction response (overwrite or set internal instrument data)

Frame header	Address	Instruction	Content	CRC Checksum (optional)	Frame end
FE	Addr	F2	0: Failure; 1: Success	High 8 digits Low 8 digits	CF FC CC FF

3.1. the zeroing range (default address is 1)

Name	Instruction	Instruction parameters	Instruction Description
Set up Zero range	Channel+ ManualRange+ PowerRang	Channel(1 bytes): Sensor channel number ; numbering starts from 0; for 0xFF Select all channels ManualRange(1 bytes): Manually clear the range; PowerRange(1 bytes): Power-on reset range ; Unit is expressed as a percentage of full scale; the parameter range is 0-100; if set to 0, then the corresponding function will be disabled	

Transmission format: FE 01 55 00 32 64 CE FC CC FF(For example, the manual zeroing range is 50%, and the power-on zeroing range is

is 100%, the hexadecimal representation of 50 is 32, and the hexadecimal representation of 100 is 64. Instruction parameter: Channel number 00; Manual clear .

Zero range 32; Power-on reset range 64.)

Frame header	Address	Instruction	Instruction parameter	Frame end
FE	01	55	00 32 64	CF FC CC FF

Return format: FE 01 F2 01 CF FC CC FF (01 Success)

Frame header	Address	Instruction	Content	Frame end
FE	01	F2	01	CF FC CC FF

4. Read instruction response (read internal instrument data)

Frame header	Address	Instruction	Instruction parameter	CRC Check (optional)	Frame end
FE	Addr	1 bytes+	1~253 bytes	High 8 bits Low 8 bits	CF FC CC FF

3.2 Gross weight reading (default address is 1)

Name	Instruction	Instruction Argument	Instruction Description
Read Gross weight	0x50	Channel	The module returns the current gross weight value to the host; the high-order byte is sent first. Channel(1 Bytes):Sensor channel number; numbering starts from 0; when set to 0xFF, Select all channels Return format: FE Addr 50 Channel Value1 Value2 Value3 Value4 CF FC CC FF

Transmission format: FE 01 50 00 CF FC CC FF (instruction parameter 00 is the channel number)

Frame header	Address	Instruction	Instruction parameter	Frame end
FE	01	50	00	CF FC CC FF

Return format: FE 01 50 00 00 00 46 CF FC CC FF(Corresponding instruction parameter content: Channel number)

The weight value read out 00 00 00 46.)

Frame header	Address	Instruction	Instruction parameter	Frame end
FE 01		50	00 00 00 46	CF FC CC FF

3.3 Continuous commands continuously (default address is 1)

Name	Instruction	Instruction Argument	Instruction Description
Continuous Send	0x07	Channel+ Enable+ DataType+ SendType+ Intervals+ Style(Optional)	Channel(1 bytes): Sensor channel number ; numbering starts from 0; when set to 0xFF, select all channels Enable(1 Byte): Enable switch ; 0x01: Continuous transmission ; 0x00: Off; DataType(1 Byte): Data Type;00:Measured Value;01:ADInternal Code Value;02:Gross Revalue;03:Net weight value;04:Peak;05:Valley;06:Peak-to-valley difference SendType(1 Byte):0x00: Send regardless of whether the data has changed; 0x01:Send only when data changes Intervals(1 bytes): The interval between consecutive transmissions; unit ms Style(1 bytes): instruction format; 0x00: Standard format; 0x01: Simplified format, see Number optional

Sent: FE 01 07 00 01 02 00 32 CF FC CC FF(Corresponding instruction parameter content: Channel number 00; Enable

Switch 01; Data type 02; Send regardless of whether the data has changed 00; Continuous transmission interval time 50ms, 50

The hexadecimal representation of is 32.)

Frame header	Address	Instruction	Instruction parameter	Frame end
--------------	---------	-------------	-----------------------	-----------

FE 01		07	00 01 02 00 32	CF FC CC FF
-------	--	----	----------------	-------------

FE 01 07 00 01 02 00 14 CF FC CC FF(Gross weight--send regardless of data changes, with an interval of 20ms)

FE 01 07 00 01 02 00 0A CF FC CC FF(Gross weight--send regardless of data changes, with an interval of 10ms)

FE 01 07 00 01 02 00 05 CF FC CC FF(Gross weight--send regardless of data changes, with an interval of 5ms)

Reply: FE 01 50 00 00 00 00 EA CF FC CC FF (The continuously occurring readings correspond to the gross weight; the instruction for gross weight is For 50)

Frame header	Address	Instruction	Instruction parameter	Frame end
FE 01		50	00 00 00 00 EA	CF FC CC FF

4. ASCII Protocol

Number Format: 7 data bits, even parity, 1 stop bit

7 One data bit, odd parity, 1 stop bit

7 1 data bit, no parity, 2 stop bits

8 1-bit data, 1-bit stop bit, odd parity

8 1-bit data, 1-bit stop bit, even parity

8 1-bit data, 1-bit stop bit, no parity (default)

8 1-bit data, 2-bit stop bits, no parity

aud Rate: 1200, 2400, 4800, **9600** (default), 19200, 38400, 57600, 115200, 230400
460800, 921,600 bps

1. Sending format

Frame header	Address	Instruction	Content	LRC Check (optional)	Frame end
:	3 Byte	1~20 bytes	0~255 bytes	2 Byte	CR LF

2. Handshake successful response

Frame header	Address	Content	LRC Verification (optional)	Frame end
:	3 Byte	OK(2 bytes)	2 Byte	CR LF

• Inger-grip command (default address is 1)

Name	Instruction	Instruction Description
Handshake	CONNECT	The module sends OK to the host after receiving the command, indicating successful handshake. Return format: : ADDR OK CR LF

Sending format: :001CONNECT

Return format: :001OK

Frame header	Address	Content
:	001	OK

3. Write instruction response (overwrite or set internal instrument data)

Frame header	Address	Content	LRC Check (optional)	Frame end
:	3 bytes	OK:Success;ER:Failure	2 bytes	CR LF

3.4.1 the zeroing range (the default address is 1)

Name	Instruction	Instruction Description
Set to zero Scope	ZERORANGE=Channel ,Manual,Power	Channel: Sensor channel number; numbering starts from 0; for... 255 Select all channels at once. Manual: Manual zeroing range; Power: Power-on reset range; The unit is a percentage of the full scale; the parameter range is: 0-100; if set to 0, the corresponding function will be disabled. Can (incompatible with version 1.X protocol)

Transmission format: :001ZERORANGE=00,50,80 (Assuming the manual zeroing range is 50%, and the power-on zeroing range is

80%)

Return format: :001OK

4. Read instruction response (read internal instrument data)

Frame header	Address	Instruction	Content	LRC Check (optional)	Frame end
:	3 Byte	1~20 bytes	0~255 bytes	2 Byte	CR LF

3.4.2 Gross weight reading (default address is 1)

Name	Instruction	Instruction Description
Read gross weight	RDGROSS=Channel	The module returns the current gross weight value to the host; Channel: Sensor channel number; numbering starts from 0; up to 255 Time selection: ALL channels return format: Addr GS=Channel,VALUE CR LF (Incompatible with Protocol Version 1.X)

Sending format: :001RDGROSS=R 00

eturn format: :001GS=0.46

10. Code hint

Use the digital tube to indicate a wrong judgment.

Serial number	Code	Content	Reason
1	Err01	Power-on zeroing error	1.The zero-setting range is set too small, and the weight exceeds the zeroing range.
2	Err02	Manual zeroing error	2.Zero the scale when the weight is unstable.
3	Err06	Steady yet unstable	
4	Err20	Data exceeds the range.	
5	Err21	The weight value is unreasonable.	
6	Err22	The weights were not placed during calibration	When the gain, no weights were placed.

7	Err25	Password entered incorrectly	
8	Err90	Sensor failure	
9	Err91	AD chip failure	



Suzhou Ouluda Intelligent Technology Co., Ltd.

Phone: 0512-6670-6550

Address: Huafeng Road, Huqiu District, Suzhou City, Jiangsu Province 288